

## 01/IV OS update

---

### **Procedure:**

- Turn the machine on while having voice 1 trigger button pressed down
- Voice 4 led should be continuously lit (and emitting an annoying sound...good to turn volume down)
- You're in update mode. Use a SySex software (with low speed transfer - around 2 KBytes/Sec) to update the SysEx onto the machine, through the midi cable.
- Power the machine off and repeat the procedure for each .Syx file
- After the update: sending midi note127 should light up the Voice 4 Led.

The update is successful.